CAPCO

QS SPECIFICATIONS

PLASTERBOARD GALVANISED CONCEALED TEE SYSTEM

RADIUSED SHADOW LINE PERIMETER TRIM

SIGMA Radiused Plaster Trim 20 White (20 x 20mm Shadow Line)

Supply and fit CAPCO Flexi Shadowground 20 White to curved wall or circular column using 6/25/55 Wall anchors at 300mm centres. Fix SIGMA Radiused Plaster Trim 20 satin white epoxy coated aluminium shadowline to the Flexi Shadowground with 15mm S.T. panhead screws at 100-300mm centres (depending on radius) to create 20 x 20mm shadow line. Flush plaster up to downstand of radiused plaster trim.

SIGMA Radiused Plaster Trim 20 Black (20 x 20mm Shadow Line)

Supply and fit CAPCO Flexi Shadowground 20 Black to curved wall or circular column using 6/25/55 Wall anchors at 300mm centres. Fix SIGMA Radiused Plaster Trim 20 Black epoxy coated aluminium shadowline to the Flexi Shadowground with 15mm S.T. panhead screws at 100-300mm centres (depending on radius) to create 20 x 20mm shadow line. Flush plaster up to downstand of radiused plaster trim.

SIGMA Radiused Plaster Trim 20 White (15 x 20mm Shadow Line)

Supply and fit CAPCO Flexi Shadowground 15 White to curved wall or circular column using 6/25/55 Wall anchors at 300mm centres. Fix SIGMA Radiused Plaster Trim 20 satin white epoxy coated aluminium shadowline to the Flexi Shadowground with 15mm S.T. panhead screws at 100-300mm centres (depending on radius) to create 15 x 20mm shadow line. Flush plaster up to downstand of radiused plaster trim.

SIGMA Radiused Plaster Trim 20 Black (15 x 20mm Shadow Line)

Supply and fit CAPCO Flexi Shadowground 15 Black to curved wall or circular column using 6/25/55 Wall anchors at 300mm centres. Fix SIGMA Radiused Plaster Trim 20 Black epoxy coated aluminium shadowline to the Flexi Shadowground with 15mm S.T. panhead screws at 100-300mm centres (depending on radius) to create 15 x 20mm shadow line. Flush plaster up to downstand of radiused plaster trim.

SIGMA Radiused Plaster Trim 50 White (50 x 50mm Shadow Line)

Supply and fit painted white 55mm X 35mm MDF board to curved wall or circular column using 6/25/55 Wall anchors at 300mm centres. Fix SIGMA Radiused Plaster Trim 50 satin white epoxy coated aluminium shadowline to the MDF Board with 16mm Wafertek screws at 100-300mm centres (depending on radius) to create 50 x 50mm shadow line. Flush plaster up to downstand of radiused plaster trim.